


SPX-3208 Distribution Box




SPX-3208 Distribution Box



Eemax SPEX3208 FlowCo Series Installation Guide and Owner Manual.



Eemax SPEX3208 FlowCo Series Product Sheet.



Call or text 888-757-4774.



View online or download Eemax FlowCo SPEX3208 Installation Manual And Owner's Manual.



Water Heater Manuals Hot Water Heater Instructions and Troubleshooting © 2023-2026, WaterHeaterManuals All rights belong to their respective owners




- Only one cold water line needed for an easy installation
- No T& P relief valve needed (check local codes); Ready to go, right out-of-the-box
- Save water and time by installing unit at the point-of-use
- ...



No venting Purge technology engages upon start-up to avoid dry-fire occurrence Easy, flexible installation Ready out of the box Over temperature protection Real-time response to flow Operation ...



SPX3A-639008, custom power distribution center with NEMA 4X; 12 sloped-top stainless steel enclosures



Power: 3kW Volts: 208V Phase: 1 Amperage: 15
Recommended Wire Size: 14



Below is a breakdown of which Bento Box® power distribution box works best for specific industries and markets. Do you need a custom power distribution box or solution to fit your unique market, industry ...

Contact Us

For more information, pricing, or custom energy solutions, please contact us:

Website: <https://gdroofing.co.za>

Email: sales@gdroofing.co.za

Phone: +27 72 418 9365

Address: 22 Electron Avenue, Isando, Johannesburg, 1600, South Africa

This document is for informational purposes only. Specifications subject to change without notice.

